INSTRUCTION MANUAL

M59/66 Yugoslavian SKS - 7.62 X 39 mm Semi-Automatic Rifle

WARNING: Before using this firearm, read carefully and follow these instructions.

Clean barrel and action before firing this rifle. Always check for barrel obstructions.



This instruction manual contains important warnings which should be read and understood before using firearms. This instruction manual should always accompany this firearm and be transferred with it upon change of ownership.



3305 Westwood Industrial Drive • Monroe, NC 28110 www.interordnance.com

CAUTION

Failure to read and understand the warrangs in this bookles may result in scripus injury to you or others, as well as damage to your freezo or other property. Please take note of the warrangs on gun funding printed here for your projection and salesy before you attempt to use this freezon.

- L. Do not rely no this or any guo's satety. Always treat this or any gun as if it were loaded and ready to fine.
- 2. Never cross a fence, jump a dich, climb a tree or hand this fivearm to anyone on a loaded condition.
- Never handle this ritle or any fincarm without first opening it yourself to check to see if it is loaded
- Never load this literarm or any tirearm until you are ready to use it to a legatmate hunting area or designated target shooting and.
- 5. Reep this firearm or any focustry and antifunition separate from each other and in a locked storage container. Do not store this rifle in a locked condition
- 6. Always wear can and eye protection when shooting this or any farction.
- Don't want shooting this firearm or any firearm tudess you are absolutely time of your target and what lies beyond your target:
- 8. Know the maximum range of your Imearm.
- Take care to always point the muzzle of this ritle or any firearm in a safe direction. Always be aware of where they rifle a muzzle is in relation to yourself and your abcompanions.
- 11) Always be sure to check the torrest of this ritle to make sure it is clear of obstructions such as ice, snow, dirt, etc., and only use and carry ammunition specifically designed and intended for use in this firearm.


WARNING

Use only original, high quality, currently immutactured immunition in this foreign. Make sure the ammunition you purchase is of the correct calibor for which this rite is chambered. You will find the calibor of this foreign inscribed on the receives. Never use ammunition of any other calaber. The caliber of this rifle is 7.62 x 39 mm M43 and is also known as 7.62 x 39 Russian Shore or 7.62 x 39 Type 50. Various manufacturers and importers of ammunition market this caliber in the United States.

The use of hundloaded, reloaded or other non-standard ammunition will void all warranties.

OPERATING INSTRUCTIONS

SKS Semi Automatic Sporting Rifle (Fig. 1)



- 1. 50/059
- 7 Topper
- 3. Trigger Count.
- 4. Magazine Release Carch
- 5. Magazine
- 6. Hayanes
- 7. Barrel
- 3 Cheming Rod
- W. Fram Sight Group
- (f) Flip-Lp Grenade Sight
- 11. Upper Handguard walls Can Cytimler
- 12. Rear Sight
- 13. Bolt Handle

- 14 Exemptor
- 15. Bult & Bols Carrier Assembly
- 16 Beceiver Cover
- 17 Receives Resummy
- 18. Strek
- P. Bull Phile
- 20. Butt Troo
- M. Hear Sling Swivel
- 22 Gas Shut-Oir (Int Single Shot (it Launcher L'ie)
- 23. NATO Standard 22min Grenade Launcher

SAFETY

The manual eafety lever is incated on the right side of the mar trigger goard bow. It is "ON" safe when the fever is in the top position (Fig.2). It is "OFF" of it the ready to fire position when the fever is in the lower position, are against the inside trace of the year trigger guard how (Fig. 3).



When in the "ON" or safe combiner, the safety blocks the frigger from being pulled back enough to release the hummer and discharge the firearm

WARNING

Never carry this rifle loaded (i.e. with a cartralge in the charabet or with immunition in the magazine) willout having the safety "ON" safe!

When placing the tifle "ON" safe or "OFF" safe (Fig 4), always keep your timeer, off the trigger and point the muzzle in a safe direction.

Fig. 4

Be sure your rule is clean and free of all grease and other proscryatives and that your ammunition is of the correct type and caliber for this rifle.



CHARGING THE RIFLE AND FIRING THE RIFLE

To chamber the first round, put the rifle on safety by pushing the safety lever with the index fineer up until the lever -wings into it) appearant position at the top of the aregor good.

Grasp the holt hundle and pull smartly to the rear of the receiver to fat as it will no and then release it to chamber the first round.

Do not ride the holt bandle down when chambering a curricule

The rifle is now leaded. By rotating the safety lever down and no the near of the frigger goard the rifle is now "OFF" safety and may be fired. Cas pressure from the firing of the earthdge with perform the work of extraction, ejection and recting of the ammunition until all rounds are expended to until a cessation of fitting is required by the user. If any ammunition is contained in the chamber or magazene of the rifle it must be immediately placed "ON" safe before unlimiting operations can commerce.

INSTRUCTIONS FOR DISASSEMBLY

Be absolutely certain that this rifle is unloaded, the safety lever is in the "ON" rate position and the magazine has been removed from the rifle before engaging in disassembly of this firearm.

 With index finger of right hand place pad or finger under this of receiver cover dismonancing not or right rear of receiver. Applying some pressure to the lab, force this up and out of its defent while pressing on the rear of the cover with the thumb of the left hand (Fig. 5).



Rotate the receiver cover pin tab up 90 degrees and work it out to the right (Fig. 6).



Fig. 6

This piece will not come out of the original and DO NOT alternat to remove a complexely from the receiver. The receiver cover will now be released from the rear or the receiver (Fig. 7). Place this part on a obean, dry surface.



Fig. 7

2. Remove the recoil spring and spring guide from the bolt assembly (Fig. 8).



For 8

3. Remove the bolt assembly by grasping the boilt handle and pulling this not buck to the rear and out of the receiver (Vity 4).



140.9



a Bolt will be left in the bolt way of the receiver. With thombs and forefinper lift use bolt out of the bolt way and place on a clean dry surface with the other puru (Fig. 10)

FIL TO

5. To remove the gas piston gode tube assembly, take the point of a ponch or a cartridge and place the point in the hole of the gas tube assembly leves on the orth side of the near sight base (Fig.

11) Coverally pry this part up until it reaches the end of its motion, but DO NOT PRY IT UP PAST ITS. GROOVE IN THE REAR SIGHT HASE.



c. Grasping the rear of the upper handguard carefully work the gos proton rod inhecupper handguard assembly up and off the barrel of the rithe (Fig. 12). If the gas proton is difficult to remove from the later assembly, use a pin punch.



on the of stullet to gently push the gas purion tube forward and out of the gas porton roof tuberapper handguard assembly (Fig. 15)



This completes the disaccombly of the rifle to allow for proper cleaning of its main groups.

REASSEMBLY

To personable the riffe, simply reverse the disassembly sequence. To make this job locs confusing, we recommend the user pay close attention to the location and position of each component pair during the disastembly procedure.

CLEANING

Although this rite has been provided with a field expedient cleaning road and not kit, any .30 caliber cleaning kit and cleaning brushes will work to properly clean the SKS. We recommend the use of proper bore solvents and light weapons labricating oil to service the rifle.

After a day's theoring, field step the rifle as described and after a brush to a cleaning tool. Dip the brush in none solvent and ergorously scrib due hore from the bresch end tream of the barrel. Brush our the brus in least ten times. Remove the bore brush from the cleaning rod and place a dry patch on its jug tip or loop end. Corefully push the patched rod through the bore so the rod wists along the curvature of the rifling. The patch will come out black. Now, with a clean, bore solvent—welled patch, carefully push this patch and subsciptent patches through the bore until a patch is almost clean. Dry out the bore with dry patches and with a clean, oil—scaked patch carefully oil the bore fool the rifle apside down so a line oil will enter the gas port of the burrel.

Now, take the gas piston and clean off the end of this piston with a touth brush or a mild stande is seed "touth brush" in order to remove carbon touling from this part and then clean the whole gas pixton with a bore cleaner—souked patch. Dry this part off completely and place on a clean, dry surface.

Take the gas piston goods tube/upper handguard assembly and with patch es and hore cleaner and a shorteness cleaning rod clean and the hore of this tube. This pair will ruis it not promptly cleaned. Clean as if you were cleaning the hore of your ride. Dry off the hore cleaning solvens and lightly off.

Inspect the bolt and bolt carrier. These parts will have a light film of carbon on the from of them. Clean this earbon footing off with bore cleaner and a rooth brush, then lightly off. Pay attention to the chamber area of this rife. Take a 45 calibra pixel brush, place on the end of a disprened cleaning rod and ratife the brush in the chamber to break loose any carbon footing in the chamber. Then wer a paren with bore solven and wrap around the brush, onsen (no the chamber and clean out the loosened carbon footing. Take a clean patch and wrap around the brush and dry out any traces of bore solvent. DO NOT OIL THE CHAMBER!

SIGHT ADJUSTMENT

Adjustment of the sight has been done at the factory. Due to Ductorious in autonomous on a lot-to-lot bases, it may become necessary to adjust the sights of your rifle.

To adjust the front sight, race the front sight adjustment low from your tool bit and insert the forked end into the hote in the front sight hood. Licease the forks of the most time fluts of the front sight poor. To move the buller's impact on the target down turn the key counter clockwise. To move the hotels's impact up turn the key clockwise.

The rear sight is of the open notch military type with adjustments available from 100 to 1000 moters (110 to 1100 yards approx.). Elevation adjustment pelfected by depressing the two spring loaded plungers on either side of the elevation slide and shiring this proce froward to elevate the sight. A 300 meter (330 yard) battle sight has been provided. Merely slide the elevation directly to the rear of the sight leaf until it stops to set the "battle sight".

SPECIFICATIONS

Caliber: 7.62 x 39mm

Muzzle Velocity: 2,440 feet per second

Rear Sight: graduated from 100 to 1,000 meters

Weight: 7 pounds (approx.) Overall Length: 59.5 (notes Burrel Length: 16.5 mone.

Capacity of Magazines 10 rounds

These M-59 rifles were recently discovered still in their original wooden crates as shipped from the famous Zastava State Arsenal to the Yugoslavian military over 40 years ago! Carefully stored in packing grease and never issued, each rifle is a beautifully preserved example of classic European craftsmanship at its best.

While other SKS rifles sport stamped receivers, short, non-descript stocks, and a finish quality which emphasizes economy over aesthetics, the M-59 exhibits the same quality craftsmanship, deep bluing, and rich oil stock finish seen on the M-48 Mauser rifles. Fitted with an integral NATO spec. grenade launcher, flip-up grenade sight, hooded front and notched rear rifle sights, and 11.5" blade bayonet, this is the rarest and smallest production variant of the SKS-type rifle ever made. Milled and machined parts, durable hardwood furniture, and 'as new' condition make this hard-to-find rifle a breed apart from Chinese SKS rifles and a true bargain for collector and sportsman alike.



3305 Westwood Industrial Drive Monroe, NC 28110 Phone (704) 225-8843 Fax (704) 225-8362 Interordinance of Americal P@ msn.com